

ESP.**MURALES**

HECHO A MEDIDA



HECHO EN EUROPA

ANCHO PANEL
50 CM/100 CM

Instrucciones de uso para murales Non Woven "N", Vinílicos "V"

DESCRIPCIÓN DEL PAQUETE

Cuando los murales tengan paneles de 50 cm de ancho, el empaquetado se realiza en dos* rollos independientes: Parte 1/2 contiene los paneles impares. Parte 2/2 contiene los paneles pares.

Cuando los murales tengan paneles de 100 cm de ancho, el empaquetado se realiza en un rollo donde los paneles estarán en orden consecutivo.

*La dimensión del mural puede afectar al número de rollos.

REVISIÓN DEL MURAL

A la recepción del pedido y antes de realizar la instalación, chequear que los rollos estén en buen estado, que el mural esté completo y que los paneles casen entre sí.

Coordonné no se responsabiliza de cualquier incidencia una vez comience la instalación.

CÓMO PREPARAR LA PARED

1. Comprobar que la pared se encuentre limpia, lisa, libre de defectos y seca.
Retirar los restos de papel anteriores.
2. Eliminar las diferencias o contrastes de color. La superficie debe tener un color uniforme.

CÓMO INSTALAR EL MURAL

1. Herramientas: Tijeras, cúter, cola celulósica para papel pintado (calidad tejido-no-tejido), pincel o rodillo, espátula de goma para papel pintado, trapo, cubeta y una regla larga.
2. Estirar los rollos y cortar cada panel por debajo de su pie o índice numérico (mantener el número para no perder el orden).
3. Ordenar todos los paneles de izquierda a derecha según el pie numérico y colocarlos frente a la superficie a empapelar.
4. Comprobar antes de la instalación que el mural esté completo y que los paneles casen entre sí.
5. Preparar en una cubeta la cola celulósica, siguiendo las instrucciones del fabricante.
6. Aplicar con pincel o rodillo la cola celulósica únicamente en la pared y repartirla de forma uniforme.
Es recomendable encolar una superficie un poco mayor que la que ocupa el panel para una mejor adherencia.
7. Adherir los paneles secos comenzando de izquierda a derecha y de arriba a abajo, presionando con la espátula de goma o con un paño para eliminar las burbujas.
8. Repetir este proceso tantas veces como paneles haya sin superponer las juntas y retirar suavemente con paño húmedo los restos de cola.
9. Cortar con cúter el papel sobrante usando una regla para guiar el trazo.

Coordonné

SÍGUENOS:  @COORDONNE  /COORDONNE  /COORDONNE

COORDONNÉ S.L. C/ MEXIC, 32, 08004, BARCELONA, SPAIN / (+34) 93 322 73 14 / WWW.COORDONNE.COM / INFO@COORDONNE.ES

EN.**MURALS****MADE TO MEASURE****MADE IN EUROPE****PANEL WIDTH****19,7" / 50 cm - 39,4" / 100 cm**

Instructions for use for Non Woven "N", Vinyl "V"

PRODUCT DESCRIPTION

When the murals have 50 cm wide panels, the package is made in two* independent rolls:

Part 1/2 contains the odd panels. Part 2/2 contains the even panels.

When the murals have 100 cm wide panels, the package is made in a roll where the panels will be in consecutive order..

* The dimension of the mural can affect the number of rolls.

REVIEW OF MURALS

Upon the reception of products and before beginning the hanging process, check that the rolls are not damaged, that the mural is complete, and that the panels match.

Coordonné will not be held responsible for any incidence once the hanging process of the mural has begun.

HOW TO PREPARE THE WALL

1. Check that the wall is clean, smooth, free from imperfections and dry. Strip all remaining wallpaper.
2. Eliminate colour differences or contrasts. The surface should be uniform in colour.

HOW TO INSTALL THE MURAL

1. Tools: Scissors, cutter, cellulose wall covering glue (non woven), brush or roller, rubber spatula for wallcoverings, cloth, bucket and a long ruler.
2. Extend the rolls and cut each panel just after its numeric footer (keep the number so as not to lose the order).
3. Arrange all the panels from left to right according to the numeric footers and lay all of them in front of the wall to be covered.
4. Check before the installation that the mural is complete and that each of the panels matches with the next.
5. Prepare the cellulose glue in a bucket following the manufacturer's instructions.
6. Apply the cellulose glue with a brush or roller only onto the wall and spread it evenly across the surface. To achieve an optimum adhesion, apply the glue to a slightly larger surface than the panel.
7. Stick the dry panels from left to right and from top to bottom, smoothing it down with a plastic wall covering spatula or a cloth to eliminate air bubbles.
8. Repeat this process until all panels are hung without overlapping the joins. With a damp cloth, softly remove glue leftovers.
9. Cut the remaining wall covering with a cutter, using a ruler to guide the cutter.

Coordonné

FOLLOW US:  @COORDONNE  /COORDONNE  /COORDONNE

COORDONNÉ S.L. C/ MEXIC, 32, 08004, BARCELONA, SPAIN / (+34) 93 322 73 14 / WWW.COORDONNE.COM / INFO@COORDONNE.ES