



Instrucciones de uso para murales

Contract "C".

DESCRIPCIÓN DEL PAQUETE

Cada mural se empaqueta en tantos rollos como sea necesario según el número de paneles siguiendo un orden consecutivo: panel 1, panel 2, panel 3...

REVISIÓN DEL MURAL

A la recepción del pedido y antes de realizar la instalación, chequear que los rollos estén en buen estado, que el mural esté completo y que los paneles casen entre sí.

Coordonné no se responsabiliza de cualquier incidencia una vez comience la instalación.

CÓMO PREPARAR LA PARED

1. Comprobar que la pared se encuentre limpia, lisa, libre de defectos y seca.
Retirar los restos de papel anteriores.
2. Eliminar las diferencias o contrastes de color. La superficie debe tener un color uniforme.

CÓMO INSTALAR EL MURAL

1. Herramientas: Tijeras, cúter, cola para papeles pintados pesados y vinílicos, pincel o rodillo, espátula de goma para papel pintado, trapo y una regla larga.
2. Estirar los rollos y cortar cada panel por debajo de su pie o índice numérico (mantener el número para no perder el orden).
3. Ordenar todos los paneles de izquierda a derecha según el pie numérico y colocarlos frente a la superficie a empapelar.
4. Comprobar antes de la instalación que el mural esté completo y que los paneles casen entre sí.
5. Aplicar con pincel o rodillo la cola únicamente en la pared y repartirla de forma uniforme.
Es recomendable encolar una superficie un poco mayor que la que ocupa el panel para una mejor adherencia.
6. Adherir los paneles secos comenzando de izquierda a derecha y de arriba a abajo, presionando con la espátula de goma o con un paño para eliminar las burbujas.
7. Repetir este proceso tantas veces como paneles haya superponiendo las juntas de los paneles aproximadamente 2 cm (debe casar el diseño de ambos paneles).
8. El área superpuesta entre paneles se eliminará con un cúter y con la ayuda de una regla para guiar el trazo. Retirar las dos tiras sobrantes.
9. Retirar suavemente con paño húmedo los restos de cola.
10. Cortar con cúter el papel sobrante usando una regla.

Coordonné





Instructions for use for Contract "C" murals.

PRODUCT DESCRIPTION

Each mural is packed in as many rolls as needed based on the number of panels in order consecutive: panel 1, panel 2, panel 3...

REVIEW OF MURALS

Upon the reception of products and before beginning the hanging process, check that the rolls are not damaged, that the mural is complete, and that the panels match.

Coordonné will not be held responsible for any incidence once the hanging process of the mural has begun.

HOW TO PREPARE THE WALL

1. Check that the wall is clean, smooth, free from imperfections and dry. Strip all remaining wallpaper.
2. Eliminate colour differences or contrasts. The surface should be uniform in colour.

HOW TO INSTALL THE MURAL

1. Tools: Scissors, cutter, heavy duty, premixed vinyl adhesive, brush or roller, rubber spatula for wall coverings, cloth and a long ruler.
2. Extend the rolls and cut each panel just after its numeric footer (keep the number so as not to lose the order).
3. Arrange all the panels from left to right according to the numeric footers and lay all of them in front of the wall to be covered.
4. Check before the installation that the mural is complete and that each of the panels matches with the next.
5. Apply the glue with a brush or roller only onto the wall and spread it evenly across the surface. To achieve an optimum adhesion, apply the glue to a slightly larger surface than the panel.
6. Stick the dry panels from left to right and from top to bottom, smoothing it down with a plastic wall covering spatula or a cloth to eliminate air bubbles.
7. Repeat this process until all panels are hung overlapping the joins approximately 2 cm/ 0,8" (both design's panels should match).
8. The overlapping area between panels will be removed with a cutter and with the help of a ruler to guide the cutting. Remove the two left over strips.
9. With a damp cloth, softly remove glue leftovers.
10. Cut the remaining wall covering with a cutter, using a ruler to guide the cutter.

Coordonné