



Instrucciones de uso para murales metálicos Gold "G" y Silver "S"

DESCRIPCIÓN DEL PAQUETE

Cada mural se empaqueta en un rollo con paneles de 100 cm/39,4" de ancho.

Si el mural es extremadamente grande, se dividirá en tantos rollos como se necesite.

REVISIÓN DEL MURAL

A la recepción del pedido y antes de realizar la instalación, chequear que los rollos estén en buen estado, que el mural esté completo y que los paneles casen entre sí.

Coordonné no se responsabiliza de cualquier incidencia una vez comience la instalación.

CÓMO PREPARAR LA PARED

1. Comprobar que la pared se encuentre limpia, lisa, libre de defectos y seca.
Retirar los restos de papel anteriores.
2. Eliminar las diferencias o contrastes de color. La superficie debe tener un color uniforme.

CÓMO INSTALAR EL MURAL

1. Herramientas: Tijeras, cúter, cola celulósica para papel pintado (calidad tejido-no-tejido), pincel o rodillo, espátula de goma para papel pintado, trapo, cubeta y una regla larga.
2. Estirar los rollos y cortar cada panel por debajo de su pie o índice numérico (mantener el número para no perder el orden).
3. Ordenar todos los paneles de izquierda a derecha según el pie numérico y colocarlos frente a la superficie a empapelar.
4. Comprobar antes de la instalación que el mural esté completo y que los paneles casen entre sí.
5. Preparar en una cubeta la cola celulósica, siguiendo las instrucciones del fabricante.
6. Aplicar con pincel o rodillo la cola celulósica únicamente en la pared y repartirla de forma uniforme.
Es recomendable encolar una superficie un poco mayor que la que ocupa el panel para una mejor adherencia.
7. Repetir este proceso tantas veces como paneles haya superponiendo las juntas de los paneles aproximadamente 2 cm (debe casar el diseño de ambos paneles).
8. El área superpuesta entre paneles se eliminará con un cúter y con la ayuda de una regla para guiar el trazo. Retirar las dos tiras sobrantes.
9. Retirar suavemente con paño húmedo los restos de cola.
10. Cortar con cúter el papel sobrante usando una regla.

Coordonné





Instructions for use for metallics Gold "G" and Silver "S" murals

PRODUCT DESCRIPTION

Each mural is packaged in a roll of panels each with 39,4"/100 cm width.

If the mural is extremely large, it will be divided into as many rolls as needed.

REVIEW OF MURALS

Upon the reception of products and before beginning the hanging process, check that the rolls are not damaged, that the mural is complete, and that the panels match.

Coordonné will not be held responsible for any incidence once the hanging process of the mural has begun.

HOW TO PREPARE THE WALL

1. Check that the wall is clean, smooth, free from imperfections and dry. Strip all remaining wallpaper.
2. Eliminate colour differences or contrasts. The surface should be uniform in colour.

HOW TO INSTALL THE MURAL

1. Tools: Scissors, cutter, cellulose wall covering glue (non woven), brush or roller, rubber spatula for wallcoverings, cloth, bucket and a long ruler.
2. Extend the rolls and cut each panel just after its numeric footer (keep the number so as not to lose the order).
3. Arrange all the panels from left to right according to the numeric footers and lay all of them in front of the wall to be covered.
4. Check before the installation that the mural is complete and that each of the panels matches with the next.
5. Prepare the cellulose glue in a bucket following the manufacturer's instructions.
6. Apply the cellulose glue with a brush or roller only onto the wall and spread it evenly across the surface. To achieve an optimum adhesion, apply the glue to a slightly larger surface than the panel.
7. Repeat this process until all panels are hung overlapping the joins approximately 2 cm/ 0,8" (both design's panels should match).
8. The overlapping area between panels will be removed with a cutter and with the help of a ruler to guide the cutting. Remove the two left over strips.
9. With a damp cloth, softly remove glue leftovers.
10. Cut the remaining wall covering with a cutter, using a ruler to guide the cutter.

Coordonné