EN. WALLPAPER ROLLS

MADE IN EUROPE

PANEL WIDTH
19,7" / 50 cm
39,4" / 100 cm

Instructions for use for non woven "N", vinyl "V", wallpaper rolls.

PRODUCT DESCRIPTION

Each roll contains 10 m/10.9 yd of continuous wallpaper made up of panels, each with a 50 cm/19.7"width.

HOW TO PREPARE THE WALL

1. Check that the wall is clean, smooth, free from imperfections and dry. Strip all remaining wallpaper.
2. Eliminate colour differences or contrasts. The surface should be uniform in colour.

HOW TO INSTALL THE WALLPAPER**

1. Tools: Scissors, cutter, cellulose wall covering glue (non-woven), brush or roller, rubber spatula for wall coverings, cloth, bucket and a long ruler.
2. Cut the first panel, using the height of the wall as a reference. Add 3 cm/1,18" at the top and the bottom. (Total height of the wall + 6 cm/2,36")
3. Prepare the cellulose glue in a bucket following the manufacturer´s instructions.
4. Apply the cellulose glue with a brush or roller only onto the wall and spread it evenly across the surface. To achieve an optimum adhesion, apply the glue to a slightly larger surface than the panel.
5. Apply the first dry panel from left to right and from top to bottom, smoothing it down with a plastic wallcovering spatula or a cloth to eliminate air bubbles.
6. Check the match of the second panel before repeating the cutting process in nº 2, and before repeating the processes in nº 4 (applying the glue) and nº 5 (applying the wall covering and smoothing it down) as many times as needed to cover the wall. The joins of the wall covering panels should not overlap.
7. With a damp cloth, gently remove glue leftovers.
8. Cut the remaining wall covering with a cutter, using a ruler to guide the cutter.

**Coordonné will not be held responsible for any incidence once the hanging process of the rollpapers has begun.

Coordonné

FOLLOW US: @COORDONNE /COORDONNE /COORDONNE

COORDONNÉ S.L. C/ MEXIC, 32, 08004, BARCELONA, SPAIN / (+34) 93 322 73 14 / WWW.COORDONNE.COM / INFO@COORDONNE.ES

ESP. ROLLOS DE PAPEL

HECHO EN EUROPA

50 CM/100 CM
ANCHO PANEL

Instrucciones de uso para rollos de papel non woven "N", vinílicos "V".

DESCRIPCIÓN DEL PAQUETE

Habitualmente cada rollo contiene 10 mt de papel continuo con un ancho de panel de 50 cm de ancho.

CÓMO PREPARAR LA PARED

1. Comprobar que la pared se encuentre limpia, lisa, libre de defectos y seca.
Retirar los restos de papel anteriores.
2. Eliminar las diferencias o contrastes de color. La superficie debe tener un color uniforme.

CÓMO INSTALAR EL PAPEL**

1. Herramientas: Tijeras, cutter, cola celulósica para papel pintado (calidad tejido-no-tejido), pincel o rodillo, espátula de goma para papel pintado, trapo, cubeta y una regla larga.
2. Cortar el primer panel tomando la altura de la pared como referencia y añadiendo 3 cm por la parte superior e inferior (total de altura pared + 6 cm).
3. Preparar la cola celulósica, siguiendo las instrucciones del fabricante, en una cubeta.
4. Aplicar con pincel o rodillo la cola celulósica únicamente en la pared y repartirla de forma uniforme. Es recomendable encolar una superficie un poco mayor que la que ocupa el panel para una mejor adherencia.
5. Adherir el primer panel seco comenzando de izquierda a derecha y de arriba a abajo, presionando con la espátula de goma con un paño para eliminar las burbujas.
6. Comprobar el case del panel segundo antes de repetir el corte del punto 2 y repetir los procesos de los puntos 4 (aplicación de cola) y 5 (adhesión y presión) tantas veces como superficie se desee empapelar.
No se superponen las juntas entre los paneles.
7. Retirar suavemente con paño húmedo los restos de cola.
8. Cortar con cutter el papel sobrante usando una regla para guiar el trazo.

**Coordonné no se responsabiliza de cualquier incidencia una vez el papel se empiece a instalar.

Coordonné